

HARMONY STUDIO CHAIR MAT INSTRUCTIONS

Thank you for your purchase! Your chair mat was rolled for quick economical shipping and may need time and warmth to relax. Please follow these steps to properly unroll your Harmony Studio chair mat.


STEP 1: WARM THE CHAIR MAT

Harmony Studio chair mats are made of premium vinyl that becomes more flexible when warm. For best unrolling results, keep the chair mat in a warm environment prior to unrolling. Your chair mat must be at least 68° F (20° C) or warmer to unroll properly.

CHOOSE ONE OF THE FOLLOWING METHODS TO WARM YOUR CHAIR MAT:



WARM ROOM
Place in a warm room for several hours.




SUNLIGHT
Lay in direct sunlight until warm.




HAIR DRYER
Gently warm using a hair dryer on low heat.
Follow safety guidelines provided by hair dryer manufacturer.

CAUTION:
Avoid overheating. Use gentle heat sources only.


STEP 2: ONCE WARMED, UNROLL SLOWLY




CLEAN SURFACE
Lay the mat on a clean, flat surface.



WEAR PROTECTION
Wear protective gloves.



UNROLL
Slowly unroll the chair mat, applying light pressure. Do not use force.




POSITION MAT
Position the mat with smooth side facing upwards.

STEP 3: FLATTEN WHERE NEEDED

Place heavy objects (books, boxes, etc.) on any areas that remain curled to help flatten your chair mat. Allow the chair mat to rest and relax naturally for 24 hours.

NOTE: *The chair mat will continue to relax with use and may take up to 24-48 hours to fully flatten. Warm environments help speed up the process.*



FLATTEN WITH WEIGHT

HELPFUL TIPS

To clean, simply wipe with a damp cloth, moistened with water. Only use mild soap if necessary. Do not use harsh chemicals or cleaners. Be sure that your chair mat is completely dry before placing on any surface.

Avoid creasing or folding the chair mat.

MADE IN USA